


Where to place Flair Smart Vents?

There are three main scenarios that are solved with Flair Smart Vents: rooms with: **too much airflow**, rooms with **too little airflow**, or wanting to create **even temperatures across the home**.

Too Little Airflow

This room gets too hot in the summer and too cold in the winter. Place a Puck in this room, and then use Pucks and a Smart Vents **for the other rooms**.



Temperature-reading device

Can be a Flair Puck, ecobee Remote Sensor, or a compatible Smart Thermostat. At least one Flair Puck is required for every home.