



Staged Heating with the Bridge Pro





Bridge Pro

A dedicated **network communication hub** with the most advanced **staged heating** control capabilities on the market.


FEATURES

- Stage heating between ductless heat pumps (DHPs) and boilers or electric baseboards.
- Cost-effective staged heating configuration options.
- Dry/Wet contacts to support up to seven boiler or electric baseboard zones.
- No C-Wire pull needed to install boiler or baseboard thermostats.

CONNECTIVITY & POWER

- For homes or businesses under 2,500 sq ft, connect the Bridge Pro (Wi-Fi or ethernet).
- For homes or businesses over 2,500 sq ft, use the Flair app to install the Bridge Pro as the networking hub (Wi-Fi or ethernet) and add the Bridge Pro as a device.
- Power using the provided AC power adapter or hardwire (24 VAC).

STAGED HEATING COMMUNICATION



Staged Heating Solution Options:

1. Use Puck Pro to control DHP and Bridge Pro to control secondary heat source.
2. Use Puck Pro to control DHP and existing thermostat to control secondary heat source.