

Staged Heating with Flair

Welcome

Congratulations on becoming a new user of the Flair hvacOS™ platform for Staged Heating! Staged Heating (Integrated Controls) is a heating control strategy for homeowners to benefit from the convenience and energy efficiency of Ductless Heat Pumps (DHPs) such as Mini Splits, but also the confidence of having secondary heat sources available during heightened cold weather conditions.

Benefits of Staged Heating

- **Improved Comfort:** Provides balanced indoor temperatures in all outdoor temperature conditions without over-reliance on one heat source.
- **Energy Cost Savings:** Reduces energy consumption by using the primary and most efficient heating source as long as possible before activating the secondary source.
- **Potential Equipment Rebates:** Many utilities and state energy programs provide rebates for equipment that meets their staged heating program requirements.
- **Optimized System Lifespan:** Distributes workload across multiple heating systems, reducing wear and tear on any single component.

How does Staged Heating with Flair work?

The most common Flair Staged Heating configuration ensures that the primary and most efficient heat source (DHP) operates until the outdoor temperature drops below its switchover condition. When this occurs, Flair switches to your boiler or electric baseboard heater(s) to provide heat. Flair switches back to the DHP when the outdoor temperature exceeds the switchover condition to ensure both reliable comfort and energy efficiency in your home. Other configurations are possible; if you have questions, please contact the Flair Support team.





Staged Heating with Flair

How do I control my Flair System?

There are two ways to control a Flair Staged Heating system — the Puck Pro(s) and the Flair App. On the next page are brief overviews of how to use the Puck Pro and Flair Application.

Puck Pro

Puck Pros function as smart controllers for your DHPs using Infrared (IR) signals. The Puck Pro also acts as a temperature and humidity sensor with an always-on display showing the room's temperature. The Puck Pro is an easy, phone-free way to quickly change basic settings like a room's setpoint temperature.



Using the Puck Pro

To change the setpoint for a room, you can rotate the Puck Pro. You can also set a room as 'Inactive' via the Puck Pro by pushing once, rotating to the 'Turn Off' screen, and pushing once more.

Flair Application

The Flair App is a mobile (iOS or Android) user-friendly interface that allows homeowners to optimize home comfort and energy use through configuration and control of its heating and cooling systems.







flair.co/ios



flair.co/android



my.flair.co



Staged Heating with Flair

Using the Flair Application

Flair Application Control Bar





Partly Cloudy 38°F / 45...

Set: 74° F Tap to Adjust

Schedule No Schedule


Manually toggle your home between Home and Away.

Displays the weather for your zip code.

Define a setpoint Select whether for your home. your system runs in auto or manual mode.

Switch between Heat, Cool and Auto modes.

Create a schedule to prioritize different areas of your home.



Staged Heating with Flair

Advanced App Features

Staged Heating is configured and supported in the Flair application, which supports other advanced features.

Schedules

Create custom schedules for different times of the day or days of the week.





To create and manage schedules on the Flair app, open the app, navigate to the "Schedule" section in the control bar, select "Create New Schedule," then define the schedule name, add individual schedule events with start/end times, choose the days of the week to apply the schedule, select the rooms you want to include, and finally, tap "Done" to save your schedule; you can edit existing schedules by accessing them from the Schedule tab.

Smart Away

Automatically adjusts temperature based on your location.





Flair "Smart Away" automatically adjusts your home's temperature when you're not home, preventing it from getting too hot or too cold, typically by turning off your HVAC system while maintaining a safe temperature range to protect pets, plants, or prevent pipes from freezing, even when you're away.

Room Sense™

Improve room temperature monitoring accuracy.





Flair "Room Sense" is a feature that monitors the temperature in individual rooms and adjusts the heating/cooling output accordingly to maintain the desired temperature in each room, providing more precise climate control throughout your home.

Auto Dry Mode

Improve room comfort by managing humidity.





"Flair Auto Dry Mode" is a setting on a Flair Puck that automatically activates the "Dry Mode" function on your DHP when the room humidity reaches a preset maximum level, dehumidifying the air without significantly changing the room temperature, making the space feel more comfortable by reducing excess moisture.

FAQ

What happens when I change a setpoint on my Staged Heating System?

When the system is in the first stage, a room's setpoint temperature should be immediately transmitted to the DHP's indoor unit. When in the second stage, adjusting the setpoint will control your boiler or electric baseboard system accordingly.

Can I connect Flair to my smart home devices?

Yes! Flair has integrations with Amazon Alexa and Hey Google/Google Assistant. Find out more information on how to connect Flair to these devices:





HEY GOOGLE flair.co/hey-google



Where can I get more information and support?

For contact options, visit:

FLAIR SUPPORT flair.co/support

